

Traditional and Pro XK-SYSTEM

LESLIE SWITCH CU-1 (optional) INSTALLATION GUIDE



Hammond Suzuki USA
733 Annoreno Drive, Addison, IL 60101
www.hammondorganco.com

Carefully follow the simple step by step instructions listed below to install your new CU-1 Leslie Switch

Step 1:

Remove the CU-1 Leslie Switch and two black knob bolts from the carton.

Step2:

Fasten the CU-1 Leslie Switch to the XK System lower manual's front rail (as shown below) by means of the two black knob bolts supplied. Please note that we have provided three mounting holes in the XK System's front rail. This allows you to mount your CU-1 Leslie Switch in two different locations.



Step 3:

Route the CU-1's cable under the XK System's Lower Manual and plug it into the "FOOT SWITCH" jack located on the rear of the XK-3c as shown below.

Step 4:

Programming the XK-3c keyboard for the CU-1 Leslie Switch.

1. Turn on the power switch located on the rear of the XK-3c.
2. Momentarily depress the "MENU" button (located below the display).
3. Momentarily depress the button labeled "#4" (located below display. Display should appear as seen in figure 1.
4. Push the button labeled "Page Up" (located to the left of the display) four times. Display should read "FOOT 1 (PHONE) DEV" as seen in figure 2.
5. Rotate adjustment knob (located below display) until the display reads "CU-1" as seen in figure 3.
6. This completes the programming of the XK-3c keyboard for the CU-1 Leslie switch.

Figure 1



Figure 2



Figure 3



NOTE:

"STOP" mode on CU-1 Leslie switch will not be functional unless "BRAKE" switch on XK-3c keyboard is activated.